

SITC 554.1
01.01.01
DTI-BMSMED

SOAP & PERFUME MAKING

**Dishwashing Liquid, Fabric Softener,
Perfume & Cologne**

**SME Briefing Session
(Handout)**

**SITC
554.1
01.01.01
DTI-
BMSMED**

**BUREAU OF MICRO, SMALL AND MEDIUM
ENTERPRISE DEVELOPMENT (BMSMED)**
Phones: (632) 890.4968 | 897.7596 | 897.1693
Email: bmsmed@dti.gov.ph
www.dti.gov.ph

SITC 574.1
01.01.01
DTI-BMSMED
no date

DEPARTMENT OF TRADE AND INDUSTRY
ULTIMA ENTREPRENEURSHIP CENTER
OCT 21 2013



ULTIMA ENTREPRENOY FORUM CENTER

G/F Nutrition Foundation of the Philippines Bldg.,
#107 E. Rodriguez Sr. Ave., Quezon City
Tel. Nos.: 411-1349; 742-0826 Telefax.: 742-7866
E-mail Address: lulu_sfmh@yahoo.com
Website: www.spicesandfoodmix.com

In cooperation with

Department of Trade & Industry

Bureau of Micro, Small and Medium Enterprise Development



SOAP & PERFUME MAKING

DISHWASHING LIQUID, FABRIC SOFTENER,
PERFUME & COLOGNE

Resource Speaker: Ms. Teresita Tamayo

DTI-BMSMED 03/2013

1 | Page

DISHWASHING LIQUID

Raw Materials	Percentage Composition	For 1 liter Finished Product
Water, deionized	76.65%	766.50 ml
Surfactant / SLES	12%	120 grams
Nonyl phenol	1 %	10 ml
Preservative	0.10 – 0.2%	1 ml
Foam booster	2-3%	30 ml
Sodium Chloride	2-4%	40 grams
Quaternary Ammonium Salt	0.1%	1 ml
Colorant	0.05%	0.5 ml
Scent	0.2-0.3%	3 ml

Procedure:

Dissolve SLES in the required amount of water. Stir until totally dissolved. Gradually add nonyl phenol with stirring. Then add foam booster and followed by the preservative. Be sure to stir the solution very well. With agitation add Sodium Chloride until a viscous solution is attained. Finally, add the rest of the raw materials and stir completely. Set aside until the bubbles subside. Transfer into an appropriate bottles and label properly.

FABRIC SOFTENER

Raw Materials	Percentage Composition	For 1 liter Finished Product
Water, deionized	95%	950 ml
DMAC	5%	50 grams
Preservative	0.1%	1 ml
Defoamer	0.05%	0.5 ml
Quaternary Ammonium Salt	0.1%	1 ml
Colorant	0.05%	0.5 ml
Scent	0.2-0.3%	3 ml

Procedure:

In a boiling water dissolve DMAC. Stir completely.

Let stand to cool down. Then add the rest of the raw materials in order as listed above. Stir for about 5 minutes.

Transfer into an appropriate container and label properly.

PERFUME & COLOGNE MAKING

<i>Raw Materials</i>	EAU DE COLOGNE	EAU DE TOILETTE	EAU DE PARFUM
Emulsifier	2 ml	2 ml	2 ml
Perfume Oil	2 ml	10 ml	15 ml
Alcohol	70 ml	70 ml	70 ml
Water	26 ml	18 ml	13 ml

Procedure:

1. Mix in chronological order with continuous agitation for 10 minutes.
2. Transfer into appropriate container and label properly.

